



ASSEMBLY INSTRUCTIONS




1. Remove the inflatable arch from the transport bag and unroll the structure

2. Attach the blower to the appropriate valve and partially inflate



3. Apply the fabric prints and join them together using the appropriate zips, then finish inflating the arch

4. Secure the inflatable arch to the ground using pegs or weights



INFLATABLE ARCH L
square portal
size 450(l)x320(h)x40(d) cm



INFLATABLE ARCH XL
shaped portal
size 650(l)x450(h)x60(d) cm



youtube.com/StudioStandSrl
for the assembly video tutorial

INFLATABLE ARCH L - squared

UPPER CROSSPIECE



- ABUNDANCE
- CUT
- SAFETY MARGIN
(Do not place important content beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff


Color profile: CMYK

Images: 100dpi - 1000dpi (for 1:10 scale files)

Fonts: converted into paths

Die path: only cutting path (where present)

INFLATABLE ARCH XL - shaped



- ABUNDANCE
- CUT
- SAFETY MARGIN
(Do not place important content beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff

Color profile: CMYK

Images: 100dpi - 1000dpi (for 1:10 scale files)

Fonts: converted into paths

Die path: only cutting path (where present)