



ASSEMBLY INSTRUCTIONS



1. Spread the stand into a vertical position



2. Pry the edges of the frame to open it.



3. Remove the transparent PVC protective sheet from inside the frame.




3. Insert the desired print.




4. Reinsert the protective sheet and close the frame. The frame is closed correctly when you hear the click.


SIZES AVAILABLE




50x70cm version



60x85cm version



70x100cm version




100x140cm version

OUTDOOR displays / Click-clack STAND

STUDIOSTANDS.it
soluzioni espositive & stampa digitale

INDICATIVE TRACK



youtube.com/StudioStandSrl
for the assembly video tutorial

— ABUNDANCE

— CUT

— SAFETY MARGIN
(Do not place important content
beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff

Color profile: CMYK

Images: 100dpi - 1000dpi (for 1:10 scale files)

Fonts: converted into paths

Die path: only cutting path (where present)

OUTDOOR displays / **Click-clack STAND**

STUDIOSTANDS.it[®]
soluzioni espositive & stampa digitale