



# DESK QUICK

## ASSEMBLY INSTRUCTIONS



1. Apply a slight push with DESK QUICK closed to start its opening.



2. Apply pressure on the support surface until the DESK QUICK starts to close.



3. Insert the fabric print into a "bag" and insert the silicone profiles present in the appropriate slots.  
NOTE: DESK QUICK can be opened and stored with the print pre-installed.



WATCH THE VIDEO TUTORIAL  
[youtube.com/studioStandSrl](https://youtube.com/studioStandSrl)

**STUDIOSTANDS.it**  
soluzioni espositive & stampa digitale

# INFO FILE

## Formats:

.eps .pdf .jpg .tiff

## Color profile:

CMYK

## Images:

included within the file at at least 100dpi resolution in 1:1 scale or 1000dpi for 1:10 scale works

## Fonts:

converted into paths

## Die path:

Keep ONLY the outermost path - all other paths must be removed

## Crop marks/register/color bars/file info:

DO NOT insert inside the file

———— **ABUNDANCE**

———— **CUT**

———— **SAFETY MARGIN**  
**(Do not place important content beyond this margin)**

1170mm

1170mm

FRONT

700mm

AREA ENTIRELY VISIBLE FROM THE FRONT

BACK

700mm

AREA ENTIRELY VISIBLE FROM THE FRONT

1135mm