



ASSEMBLY INSTRUCTIONS

FRONT




SIDE



1. Insert the support rod into the shape of the pedestal and secure with the screws supplied

BOTTOM

SIDE




2. Modular disc for horizontal or vertical orientation of the display


SIDE




3. Apply one of the two halves of the disc to the interlocking support rod




4. Apply the remaining half of the shaped disc to the back of the music stand



5. Assemble the metal cylinder by inserting the spring, the metal washer and the plastic closing washer



6. Apply the lectern to the support rod by matching the two halves of the shaped disc, insert the screw and secure using the cylinder



7. Apply the communication holders to the structure by inserting the pins into the appropriate holes in the lectern



8. Insert the printouts in the appropriate pocket of the communication holder


NOTE:

Sherpa Lectern can be used in horizontal or vertical orientation.

Other versions available with bench or wall support.



youtube.com/StudioStandSrl
for the assembly video tutorial



- ABUNDANCE
- CUT
- SAFETY MARGIN**
(Do not place important content beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff
Color profile: CMYK
Images: 100dpi - 1000dpi (for 1:10 scale files)
Fonts: converted into paths
Die path: only cutting path (where present)