1. Fold the faces of the PRISMA display along the punched lines to form a triangle


2. Match the holes with the external parts to close the structure then position PRISMA horizontally/vertically depending on the customization

NOTE - The current version of the product includes closure with double-sided tape supplied.

OUTDOOR displays / PRISMA

STUDIOSTANDS.it®
soluzioni espositive & stampa digitale

2020 mm

PRINTING
AREA
BRING THE TRACK TO
DIMENSIONS INDICATED

1420mm

ABUNDANCE

CUT

SAFETY MARGIN
(Do not place important content
beyond this margin))

OUTDOOR displays / PRISMA

STUDIOSTANDS.it ®
soluzioni espositive & stampa digitale