# ASSEMBLY INSTRUCTIONS

1. Extend the telescopic rod and act on the various sections to block the parts.

2. Remove the screw at the bottom of the telescopic pole.

3. Insert the screw into the hole in the metal stand and attach the rod to the base.

Velcro di fissaggio

**3.** Insert the structure into the print slot and secure with the Velcro straps

NOTE

As an alternative to the standard base, Vela can be accessorized with other types of pedestal
See the section **"OPTIONAL BASES"** on our e-commerce.

OUTDOOR displays / VELA

STUDIOSTANDS.it ®
soluzioni espositive & stampa digitale

435mm

1887mm

PRINTING AREA

BRING THE TRACE TO THE DIMENSIONS INDICATED

110mm

1

2

1190mm

1190mm

60mm

NOTE
ELEMENTS 1 AND 2
WILL BE USED FOR
COMPLETE THE DISPLAY SLOTH

──── ABUNDANCE

──── CUT

──── SAFETY MARGIN
(Do not place important content
beyond this margin))

OUTDOOR displays / VELA

STUDIOSTANDS.it ®
soluzioni espositive & stampa digitale

**1.** Assemble the rod by simply snapping the tubulars together

2. Insert the structure into the slot of the print. Use the ties to secure the print to the chosen base.

NOTe

As an alternative to the standard base, it is possible to accessorize Vela Big with various types of pedestal
See the section **"OPTIONAL BASE"** on our e-commerce.

703mm

2506mm

PRINTING AREA

BRING THE TRACE TO THE DIMENSIONS INDICATED

73,5mm

1

2

1600mm

1597mm

112mm

NOTE
ELEMENTS 1 AND 2
WILL BE USED FOR
COMPLETE THE DISPLAY SLOTH

—— ABUNDANCE

—— CUT

—— SAFETY MARGIN
(Do not place important content
beyond this margin))

OUTDOOR displays / VELA BIG

STUDIOSTANDS.it®
soluzioni espositive & stampa digitale