


ASSEMBLY INSTRUCTIONS



1. Extend the telescopic rod and act on the various sections to block the parts.



2. Remove the screw at the bottom of the telescopic pole.



3. Insert the screw into the hole in the metal stand and attach the rod to the base.




3. Insert the structure into the print slot and secure with the Velcro straps




NOTE

As an alternative to the standard base, Vela can be accessorized with other types of pedestal
See the section **"OPTIONAL BASES"** on our e-commerce.

youtube.com/StudioStandsSrl
for the assembly video tutorial





NOTE

ELEMENTS 1 AND 2
WILL BE USED FOR
COMPLETE THE DISPLAY SLOTH

ABUNDANCE

CUT

SAFETY MARGIN
(Do not place important content
beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff
Color profile: CMYK
Images: 100dpi - 1000dpi (for 1:10 scale files)
Fonts: converted into paths
Die path: only cutting path (where present)

OUTDOOR displays / VELA

STUDIOSTANDS.it®
soluzioni espositive & stampa digitale



1. Assemble the rod by simply snapping the tubulars together




2. Insert the structure into the slot of the print. Use the ties to secure the print to the chosen base.

NOTe

As an alternative to the standard base, it is possible to accessorize Vela Big with various types of pedestal
See the section **“OPTIONAL BASE”** on our e-commerce.





NOTE

ELEMENTS 1 AND 2
WILL BE USED FOR
COMPLETE THE DISPLAY SLOTH

ABUNDANCE

CUT

SAFETY MARGIN
(Do not place important content
beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff
Color profile: CMYK
Images: 100dpi - 1000dpi (for 1:10 scale files)
Fonts: converted into paths
Die path: only cutting path (where present)

OUTDOOR displays / VELA BIG

STUDIOSTANDS.it®
soluzioni espositive & stampa digitale