

PRINT APPLICATION AND ASSEMBLY INSTRUCTIONS



1. Apply the print to the metal profile using double-sided tape.



2. Insert the profile with the print applied inside the remaining profile.



3. Inserire il profilo con la stampa applicata dentro al profilo rimanente.



4. Complete the operation by applying the black plastic caps.




ATTENTION THE MECHANISM LOCKING KEY MUST BE INSERTED INTO THE STRUCTURE TO CARRY OUT THIS OPERATION.

5. Apply the bottom part of the print to the plastic tab that protrudes from the structure - **for further fixing we recommend the application of staples in addition to double-sided tape**



6. Remove the locking key of the print winding mechanism then rewind the graphic inside the structure.



7. Apply the pedestals to the structure, matching the pin present with the hole. Lock by acting on the levers present.



8. Assemble the support rod and insert it into the appropriate hole on the structure.




9. Extract the print from the structure until applying the shaped profile to the rod (repeat the operation for double-sided setups).



[youtube.com/StudioStandsSrl](https://www.youtube.com/StudioStandsSrl)
for the assembly video tutorial

OUTDOOR displays / **ROLL-OUT**

STUDIOSTANDS.it
soluzioni espositive & stampa digitale



- ABUNDANCE
- CUT
- SAFETY MARGIN
(Do not place important content beyond this margin))

INFO FILE

Formats: .eps .pdf .jpg .tiff
Color profile: CMYK
Images: 100dpi - 1000dpi (for 1:10 scale files)
Fonts: converted into paths
Die path: only cutting path (where present)