


ASSEMBLY INSTRUCTIONS

BACK VIEW



1. Extract the modular rods from the rear compartment of the frame




2. Assemble the support rods

TOP VIEW



3. Rotate the feet, attached to the lower part of the frame, in a perpendicular position compared to the structure.

TOP VIEW




4. Insert the composite rods in the pedestal's holes.
WARNING - make sure that the rods are perpendicular to the ground

TOP VIEW



5. Remove the locking key of the print winding mechanism, then extract the print simply by pulling it.
Attach the pole to the top profile

WARNING - the plug at the base of the display prevents the rewinding when inserted. Please take out the plug only after the banner has been attached. In case of print replacement the plug must be reinserted before changing the print.



youtube.com/StudioStandsSrl
for assembly video tutorial

INDICATIVE LAYOUT



BLEED

CUT LINE

SECURITY MARGIN

(Do not position important content outside this margin)

FILE INFO

File type: .eps .pdf .jpg .tiff

Color profile: CMYK

Images: 100dpi - 1000dpi (for 1:10 scale file)

Font: converted into vector paths

Layout lines: only cut line (where present)

INSTRUCTIONS FOR MOUNTING /REPLACING THE PRINT

Operation performed by our operators for orders with the “structure + print” solution



1. WARNING -THE KEY OF THE LOCKING MECHANISM HAS TO BE INSERTED IN THE STRUCTURE TO DO THIS OPERATION.

Apply the bottom of the print to the plastic tab that comes out of the structure - **for further fastening we recommend applying metal stitches in addition to double-sided tape.**



2. Insert the top edge of the print in the clic-clack profile.



3. Remove the locking key of the print winding mechanism and then rewind the print inside the frame.